

# Software Release Notes XS9700HDPLUS

**Software Upgrade instructions:** Copy software file into USB and connect USB to finder wait for few seconds  
Press **MENU** => **Upgrade** => **Software Upgrade** => Update & Backup <**USB Upgrade**> | Section **ALL** | **File Path** press OK  
and select the software file and press OK | Start **Press OK** to start the upgrade process | Once the software is loaded  
finder will be turned OFF, press POWER BUTTON on finder to turn ON and wait for upgrade process to complete, once

**Warning:** Make sure the battery is 50% or Charger is connected  
Never power OFF the finder while its being upgrade !

## Version 2.1.5.1132

Release Date 2021-08-17 14:24:52

Model Xcruiser XS9700HDPLUS

HW Ver 12.0

| Serial | Improvements and Changes  | Remarks |
|--------|---|---------|
| 1      | TP Analyzer Added, While in FINDING menu press F4 to open TP Analyzer,<br>TP Analyzer will auto detect Vertical Low, Horizontal Low, Vertical High and Horizontal High<br>Frequencies | Added   |
| 2      | Spectrum Analyzer settings were going back to default after exit or finder reboot solved  | Solved  |

## Version 2.1.5.1080

Release Date 2021-06-18 16:00:54

Model Xcruiser XS9700HDPLUS

HW Ver 12.0

| Serial | Improvements and Changes   | Remarks   |
|--------|--|-----------|
| 1      | While in Spectrum Analyzer LEVEL value was not updating          | Solved    |
| 2      | Signal Strength and Quality values optimized as previous version | Optimized |

## Version 2.1.5.1053

Release Date 2021-05-11 08:40:42

Model Xcruiser XS9700HDPLUS

HW Ver 12.0

| Serial | Improvements and Changes                               | Remarks  |
|--------|--|----------|
| 1      | C/N (Carrier Noise) unstable and incorrect value issue | Solved   |
| 2      | Unable to power OFF finder with remote control         | Solved   |
| 3      | Display Screen Drivers updated                         | Improved |

Version 2.1.5.1009

Release Date 2021-04-15 11:38:03

Model Xcruiser XS9700HDPLUS

HW Ver 12.0

|   |   |          |
|---|---|----------|
| 1 | Adding new TP, if the same TP exist then message will show and can jump to the existing TP  | Improved |
| 2 | While in LIVE TV mode and press FIND key will open FINDING menu with the current channel SAT and FREQUENCY  | Solved   |
| 3 | While in LIVE TV mode press F1 key to open INFOBAR if press F1 key again it will open Signal Indicator and if press F1 key again then Signal Indicator will show information about the current channel bitrate in KBPS and signal details as SNR:-   C/N:-   MER:-   and PWR:-                  | Added    |
| 4 | Strength Buzzer, Finder will start the buzzer sound with strength level increasing/decreasing, this will help installer to location and position the dish by hearing the buzzer, this buzzer can be turned OFF from <b>Menu =&gt; Setting =&gt; Finder Setting =&gt; Strength Buzzer ON/OFF</b> | Added    |
| 5 | Recording a channel without using remote control, While in LIVE TV mode press OK to open channel list and go to any channel you would like to record in USB, and press FIND key will open a dialog box with option to RECORD cancel, repeat the same steps to stop the recording                | Added    |
| 6 | While in FINDING menu press F3 to detect the signal and identify the satellite position   | Added    |
| 7 | While in FINDING menu press F1 to open signal ZOOM now you can press LEFT/RIGHT keys to change the transponders   | Improved |
| 8 | While in FINDING menu go to FREQUENCY<br>Press OK key to open the frequency LIST (Press LEFT/RIGHT will move list page by page)<br>Press LEFT/RIGHT to change the Frequency<br>Press numbers directly to EDIT the frequency - polarity - & - symbol rate  | Improved |